



# BUILD A BETTER FREESTANDING DECK FROM THE GROUND UP

## LIGHTWEIGHT AND STRONG

18X lighter than cement footings, each BLOCK only weighs 2.16 lbs but is load rated to support 1,800 lbs.

## EASY TO INSTALL

BLOCKS are simple and fast to place and reposition—no digging, chipping out slots, or back pain required. You can also install them on uneven ground with a little leveling.

## LONG-LASTING DURABILITY

The UV-protected BLOCK comes with a 30-year warranty, will not chip, crack, or corrode, is cold-weather approved to resist frost heave, and is vented to prevent water build-up, rot, and mold.



CAMO BLOCK is made from recycled single-use bottle caps and can be recycled at the end of its life.



BLOCK is backed by a 30-year warranty to hold up on the job.

Read the full warranty at [camofasteners.com](https://www.camofasteners.com)



**HOW TO**



PLACE BLOCK PIERS AT THE CORNERS OF YOUR PROJECT.



SET AND FASTEN RIM JOISTS OR POSTS AND FRAMING.




PLACE BLOCKS IN THE FIELD NO MORE THAN 5 FT. APART FROM EACH OTHER AND SO YOUR JOISTS ARE 16 IN. ON CENTER.

**BLOCK WORKS WITH 2X4, 2X6, OR 2X8 WOOD JOISTS, 2 IN. METAL JOISTS, AND 4X4 AND 6X6 POSTS.**




**USE BLOCK FOR VARIOUS PROJECTS**

**Freestanding deck projects 5-1/2 in. to 5 ft. tall**



**Freestanding deck projects 5-1/2 in. to 5 ft. tall**



USE BLOCK WITH OTHER CAMO INNOVATIONS TO BUILD A BETTER DECK UP TO

**5X FASTER**



FASTENERS



LEVER



DRIVE



BLOCK